

To Start Honda EU2000i Generators

- Turn fuel tank cap vent lever **ON** (it's on the top of the generator's gas tank cap)
- Turn engine switch **ON** (it's on the bottom of generator)
- Close the choke (push choke lever to the right)
- Turn Eco-Throttle switch to its **OFF** position (Eco-Throttle decreases generator's RPMs when the electrical load is lighter, and provides quieter operation)
- ...start generator...
- ...after a minute or two of generator warmup, open the choke (push choke lever to the left) and turn the Eco-Throttle switch to its **ON** position

